


7x15W 4IN1 Magic Pixel Blade LED Moving Bar Light



This product manual contains important information about the safe installation and use of this projector. Please read and follow these instructions carefully and keep this manual in a safe place for future

User manual

Please read the instructions carefully before use

TABLE OF CONTENTS

1.Safety Instruction 2

2.Technical Specification 4

3.How to Control The Devicee5

4.Diagram 10

5.Trouble Shooting11

6.Fixture Cleaning 12

STATEMENT

The product has well capability and intact packing when leave factory. All of the user should comply with warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can not be responsible for any malfunction & problem owing to ignore the manual.

1.Safety Instruction

Please keep this User Guide for future consultation. If you sell the unit to another user, be sure that they also receive this instruction booklet.

Unpack and check carefully there is no transportation damage before using the unit.

Before operating, ensure that the voltage and frequency of power supply match the power requirements of the unit.

It’s important to ground the yellow/green conductor to earth in order to avoid electric shock.

The unit is for indoor use only. Use only in a dry location.

The unit must be installed in a location with adequate ventilation, at least 50cm

from adjacent surfaces. Be sure that no ventilation slots are blocked.

Disconnect main power before replacement or servicing.

Make sure there are no flammable materials close to the unit while operating as it is fire hazard.

Use safety cable when fixes this unit. DO NOT handle the unit by taking its head only, but always by taking its base.

Maximum ambient temperature is T_a : 40°C . DO NOT operate it where the temperature is higher than this Unit surface temperature may reach up to 85°C . DO NOT touch the housing bare-hand during its operation. Turn off the power and allow about 15 minutes for the unit to cool down before replacing or serving.

In the event of serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.

DO NOT touch any wire during operation as high voltage might be causing electric shock.

WARNING:

To prevent or reduce the risk of electrical shock or fire, do not expose the unit to rain or moisture.

DO NOT open the unit within five minutes after switching off.

The housing, the lenses, or the ultraviolet filter must be replaced if they are visibly damaged.

CAUTION:

There are no user serviceable parts inside the unit. DO NOT open the housing or attempt any repairs yourself. In the unlikely event your unit may require

service, please contact your nearest dealer.

INSTALLATION:

The unit should be mounted via its screw holes on the bracket. Always ensure that the unit is firmly fixed to avoid vibration and slipping while operating. And make sure that the structure to which you are attaching the unit is secure and is able to support a weight of 10 times of the unit's weight. Also always use a safety cable that can hold 12 times of the weight of the unit when installing the fixture. The equipment must be fixed by professionals. And it must be fixed at a place where is out of the touch of people.

2. Technical Specification

Power Voltage: AC 100-240V, 50/60Hz

Power Consumption: 120W

Light Sources: 7 Multi-chip 4in1 RGBW 15 Watt LED sources

Beam Angle: 4°

Control

DMX Channel: 15/39 Channel

Control Modes: DMX512, Auto, Master-Slave, Music

Pan/Tilt

Continuous PAN and TILT rotation

Pan/Tilt Resolution: 16 bit

Construction

Display: LCD Display

DMX In/Out socket: 3-pin XLR sockets

Power Socket: Powercon in

Protection Rating: IP20

Features

85% optic efficiency

High-efficiency 67 mm PMMA optics

Continuous PAN and TILT rotation

Flicker free sources management, suitable for TV applications and all video

High-resolution stepper motors operated via microprocessors ensure extreme accuracy and smooth movements.

Variable strobe effects

Size

Dimension: 58*17*25cm

Packing Size:640*320*245MM

Weight

Net Weight: 9Kgs

Gross Weight: 11Kgs

3.How to Control The Device

The DMX512 is widely used in intelligent lighting control,with a DMX 512 controller.connect several lights together,dmx in and dmx out, 3 pin XLR connectors: Pin 1: GND, Pin 2: Negative signal (-), Pin 3: Positive signal (+)




Figure2

XLR Pin Configuration

pin1=Ground
pin2=Data Compliment (negative)
pin3=Data true (positive)

Display:

MENU To select the programming functions
 DOWN To go backward in the selected functions
 UP To go forward in the selected functions
 ENTER To confirm the selected functions

Set DMX Address Code

1. Press "**Menu**" to "DMX SET", and press "**ENTER**" keys to enter into
2. Show "Set DMX Address DMX Address:001", Press the "**UP** and **DOWN**" keys to amended
3. Press "**ENTER**" keys to save and Exit, Press the "**MENU**" Keys does not save and Exit

DMX SET	Address=001		
Mode	DMX CH	15 or 39 Channels	
	Auto 1	Fast Auto running mode	
	Auto 2	Slow Auto running mode	
	Sound Mode	Sound Control Mode	
Sound Sense	0-255	Sensitivity Adjustment	
Pan Invert	OFF		
	ON		
Tilt Invert	OFF		
	ON		
Manual	Manual CH01	=000	
	Manual CH02	=000	
	Manual CH03	=000	
	
	Manual CH15	=000	
Reset	Motor	Pan/Tilt reset	
	Factory	All reset	
Offset Correct	Pan	Pan offset	
	Tilt	Tilt offset	

15/39 DMX channels mode:


Mode		Value	Function
15CH	39CH		
1	1		<u>PAN Movement 8bit :</u>
		0-255	Pan Movement
2	2		<u>Pan Fine 16bit :</u>
		0-255	Fine control of Pan movement
3	3		<u>TILT Movement 8bit :</u>
		0-255	Tilt Movement
4	4		<u>Tilt Fine 16bit :</u>
		0-255	Fine control of Tilt movement
5	5		<u>Pan Continue Rotation :</u>
		0-127	Forward fast to slow
		128	Stop
		129-255	Backward slow to fast
6	6		<u>Tilt Continue Rotation :</u>
		0-127	Forward fast to slow
		128	Stop
		129-255	Backward slow to fast
7	7		<u>Speed Pan/Tilt movement :</u>
		0-255	Speed fast to slow
8	8		<u>Dimmer :</u>
		0-255	Dimmer from 0%~100%
9	9		<u>Strobe :</u>
		0-9	Closed
		10-85	Strobe from slow to fast
		86-170	Raiden strobe from slow to fast
		171-255	Random strobe from slow to fast
10	10		<u>LED Macro :</u>
		0-9	No Function
		10-74	Static macro
		75-110	Dynamic macro 1 from slow to fast

		111-146	Dynamic macro 2 from slow to fast
		147-182	Dynamic macro 3 from slow to fast
		183-218	Dynamic macro 4 from slow to fast
		219-255	Dynamic macro All from slow to fast
11	11		<u>All Red : [LED Macro Valid]</u>
		0-255	Red Color (0%~100%)
12	12		<u>All Green : [LED Macro Valid]</u>
		0-255	Green Color (0%~100%)
13	13		<u>All Blue : [LED Macro Valid]</u>
		0-255	Blue Color (0%~100%)
14	14		<u>All White : [LED Macro Valid]</u>
		0-255	White Color (0%~100%)
*	11		<u>Red LED-array 1: [CH10 Invalid]</u>
		0-255	Red Color (0%~100%)
*	12		<u>Green LED-array 1: [CH10 Invalid]</u>
		0-255	Green Color (0%~100%)
*	13		<u>Blue LED-array 1: [CH10 Invalid]</u>
		0-255	Blue Color (0%~100%)
*	14		<u>White LED-array 1: [CH10 Invalid]</u>
		0-255	White Color (0%~100%)
*	15		<u>Red LED - array 2 :</u>
		0-255	Red Color (0%~100%)
*	16		<u>Green LED - array 2 :</u>
		0-255	Green Color (0%~100%)
*	17		<u>Blue LED - array 2 :</u>
		0-255	Blue Color (0%~100%)
*	18		<u>White LED - array 2 :</u>
		0-255	White Color (0%~100%)
*	19		<u>Red LED - array 3 :</u>
		0-255	Red Color (0%~100%)
*	20		<u>Green LED - array 3 :</u>
		0-255	Green Color (0%~100%)

*	21		<u>Blue LED - array 3 :</u>
		0-255	Blue Color (0%~100%)
*	22		<u>White LED - array 3 :</u>
		0-255	White Color (0%~100%)
*	23		<u>Red LED - array 4 :</u>
		0-255	Red Color (0%~100%)
*	24		<u>Green LED - array 4 :</u>
		0-255	Green Color (0%~100%)
*	25		<u>Blue LED - array 4 :</u>
		0-255	Blue Color (0%~100%)
*	26		<u>White LED - array 4 :</u>
		0-255	White Color (0%~100%)
*	27		<u>Red LED - array 5 :</u>
		*0-255	Red Color (0%~100%)
*	28		<u>Green LED - array 5 :</u>
		0-255	Green Color (0%~100%)
*	29		<u>Blue LED - array 5 :</u>
		0-255	Blue Color (0%~100%)
*	30		<u>White LED - array 5 :</u>
		0-255	White Color (0%~100%)
	31		<u>Red LED - array 6 :</u>
		0-255	Red Color (0%~100%)
	32		<u>Green LED - array 6 :</u>
		0-255	Green Color (0%~100%)
	33		<u>Blue LED - array 6 :</u>
		0-255	Blue Color (0%~100%)
	34		<u>White LED - array 6 :</u>
		0-255	White Color (0%~100%)
	35		<u>Red LED - array 7 :</u>
		0-255	Red Color (0%~100%)
	36		<u>Green LED - array 7 :</u>
		0-255	Green Color (0%~100%)

	37		<u>Blue LED - array 7 :</u>
		0-255	Blue Color (0%~100%)
	38		<u>White LED - array 7 :</u>
		0-255	White Color (0%~100%)
15	39		<u>Function :</u>
		0-251	No function
		252-255	Reset (3 second)

4. Diagram



5. Trouble Shooting

Following are a few common problems that may occur during operation. Here are some suggestions for easy troubleshooting:

a. The unit does not work, no light and the fan does not work

1. Check the connection of power and main fuse.
2. Measure the mains voltage on the main connector.
3. Check the power on LED.

b. Not responding to DMX controller

1. DMX LED should be on. If not, check DMX connectors, cables to see if link properly.
2. If the DMX LED is on and no response to the channel, check the address settings and DMX polarity.

3. If you have intermittent DMX signal problems, check the pins on connectors or on PCB of the unit or the previous one.
4. Try to use another DMX controller.
5. Check if the DMX cables run near or run alongside to high voltage cables that may cause damage or interference to DMX interface circuit.

c. One of the channels is not working well

1. The stepper motor might be damaged or the cable connected to the PCB is broken.
2. The motor's drive IC on the PCB might be out of condition.

6. Fixture Cleaning

The cleaning of internal and external optical lenses and/or mirrors must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the unit's optics.

- **Clean with soft cloth using normal glass cleaning fluid.**
- **Always dry the parts carefully.**
- **Clean the external optics at least every 20 days. Clean the internal optics at least every 30/60 days.**